

Technical Specs for a *Who's Your One* Display Case

Use the specs and information below to help your church create a display case to use in your *Who's Your One* emphasis.

Adapt as needed for your context.

Who's Your **ONE**?

This display case is designed to hold ping-pong balls representing ones who have been identified, prayed for, and reached with the gospel. For more information, refer to the **Who's Your One? Implementation Guide**.



SPECIAL TOOLS NEEDED

Who's Your **ONE?**

Circular Saw Blade for Cutting Acrylic Sheet

Echo Corner 6½ Inch Aluminum Cutting Circular Saw Blade, Fast Dry Cool Clean Cut Off Non-Ferrous Metal Plate/Sheet/Tube, Polycarbonate, Plastics

Available at Amazon

[LINK](#)

[Instructional Video](#)



½" Transfer Punch

Available at Amazon

[LINK](#)



½" Step Drill Bit

Available at Amazon

[LINK](#)



PZ2 (Pozi 2) Screwdriver or PZ2 Bits

Available at Amazon

[LINK](#)



[LINK](#)



MATERIALS & HARDWARE NEEDED

Who's Your **ONE?**

1/4" x 48" x 96" Acrylic Sheet

Available at Home Depot

[LINK](#)



IPS Weld-On 3 Acrylic Plastic Cement with Applicator Bottle with Needle, 4 oz Can, Clear

Available at Amazon

[LINK](#)

[Instructional Video](#)




Fischer DuoBlade S Self-Drilling Drywall Anchor (25 Pieces)

Available at Amazon

[LINK](#)

[Instructional Video](#)



8

Osring 1in Dia x 2in L Wall Standoffs Stainless Steel Sign Standoff Holder, Brushed Nickel (Order 2 Pks of 8)

Available at Amazon


[LINK](#)



2 Packs of 8
Required


CUT ACRYLIC SHEET

Who's Your **ONE?**





DRILL $\varnothing\frac{1}{2}$ " HOLES FOR STANDOFFS

Who's Your ONE?




Use 1/2" step drill bit for best results.

1



Apply painter's tape to the perimeter of the cut acrylic. Center the tape 1.5" from the edge. This will make it much easier to mark the clear acrylic prior to drilling.

2




Carefully drill the acrylic using a 1/2" Step Drill Bit. This will greatly reduce the chance of cracking the acrylic.

3



Clean finished holes.


4



Use a 1/2" Center Punch to accurately transfer the center of each drilled hole to wall to locate wall anchors.

DETERMINE MOUNTING HEIGHT

Who's Your **ONE?**




TYPICAL MOUNTING HEIGHT: Center of sign is 60" from the ground (vertically)

INSTALL ANCHORS AFTER MARKING LOCATIONS ON WALL

Who's Your **ONE?**

Use Screw Driver to carefully and precisely install wall anchors.



Use screws included with
DuoBlade S Anchors to
mount Standoffs.

*(Do not use the screws
included with standoffs)*




Carefully screw standoff
into the wall anchor until
snug. Do not overtighten.



BOND SIDES OF THE ACRYLIC SHEET

Who's Your **ONE?**



Carefully bond sides and bottom to acrylic panel using Acrylic Cement (Weld-on 3). Do this **after** transferring mounting locations to wall.

MOUNT DISPLAY TO WALL WITH STANDOFFS

Who's Your **ONE?**

VERY IMPORTANT: use two clear washers per standoff. One on each side of the acrylic. This is to prevent cracking the acrylic.



Do **NOT** over-tighten.



ADD LOGO TO DISPLAY

Who's Your **ONE?**

